







Parts list:

							
① x 1 pc	② x 1 pc	③ x 2 pcs	④ x 2 pcs	⑤ x 1 pc	⑥ x 1 pc	⑦ x 2 pcs	⑧ x 2 pcs
							
⑨ x 2 pcs	⑩ x 1 pc	⑪ x 1 pc	⑫ x 1 pc				

Hardware list:

										
Ⓐ x8 (M8x20)	Ⓑ x4 (M6x10)	Ⓒ x4 (M6x8)	Ⓓ x8 (M6x12)	Ⓔ x2 (St3.5x16)	Ⓕ x2 (St3.9x22)	Ⓖ x1 (4mm)	Ⓗ x1 (5mm)	Ⓘ x2	Ⓝ x8	Ⓚ x8 (M10x8)


Step 1



- Insert tube (item 9) into tube (item 7&8) .
- Do not fully tighten screws until step 5.


	
(H)x1	(K)x8

Step 2




	
A x 8	H x 1

Step 3




	
Dx8	Hx1

Step 4






			
Bx4	Gx1	Ix2	Jx8



Step 5




Loosen screws on one side and slide to the desired width, then tighten. Loosen screws on the other side and slide to the desired width , then tighten.




Step 6






a.



b.




c.



	
E x 2	F x 2

Step 7



	
Cx4	Gx1